

OPTIONS AND ACCESSORIES

Options

1. Accessories (for LC2H total counter)

Panel cover (black)



Part No.: AEL3801

You can change the design of the front panel by replacing it with this black panel cover. The counter comes with an ash gray panel cover as standard.

Note: No panel cover accessory (black) is available for the LC2H preset counter.

2. Lithium battery (3 V)



Part No.: ATH3802

Packaged with the LC2H (excluding the PC board mounting type).


Warning

- Make sure the “+” and “-” polarities are positioned correctly.
- Do not throw the old battery into a fire, short circuit it, take it apart, or allow it to come into contact with heat.
- The battery is not rechargeable.

3. Installation parts

Mounting frame

(Suitable for installation frame type LC2H total counter and LC2H preset counter)




Part No.: ATH3803

Packaged with the mounting bracket type LC2H total counter

Rubber gasket

(Suitable for installation bracket type LC2H total counter and LC2H preset counter)



Part No.: ATH3804

Packaged with the mounting bracket type LC2H total counter

Options

1. Accessories (for LH2H hour meter)

Panel cover (black)



Part No.: ATH3801

You can change the design of the front panel by replacing it with this black panel cover. The counter comes with an ash gray panel cover as standard.

Note: No panel cover option (black) is available for the LH2H preset hour meter.

2. Lithium battery (3 V)



Part No.: ATH3802

Packaged with the LH2H (excluding the PC board mounting type).


Warning

- Make sure the “+” and “-” polarities are positioned correctly.
- Do not throw the old battery into a fire, short circuit it, take it apart, or allow it to come into contact with heat.
- The battery is not rechargeable.

3. Installation parts

Mounting frame

Suitable for installation frame type LH2H hour meter and LH2H preset hour meter



Part No.: ATH3803

Packaged with the mounting bracket type LH2H hour meter

Rubber gasket

Suitable for installation frame type LH2H hour meter and LH2H preset hour meter











Part No.: ATH3804

Packaged with the mounting bracket type LH2H hour meter













DIN SIZE COUNTERS COMMON OPTIONS

Terminal sockets (Unit: mm inch, Tolerance: $\pm 1 \pm .039$)

| Type | Appearance | Dimensions | Terminal wiring (Top view) | Mounting hole dimensions |
|---|---|--|---|---|
| LC4H (8-pin type) | <ul style="list-style-type: none"> • DIN rail socket (8-pin)  <p>ATC180031</p> |  |  <p>Note: Terminal No. on the main body are identical to those on the terminal socket.</p> |  |
| LC4H LC4H-S LC4H-W (11-pin type) | <ul style="list-style-type: none"> • DIN rail socket (11-pin)  <p>ATC180041</p> |  |  <p>Note: Terminal No. on the main body are identical to those on the terminal socket.</p> |  |

Note: The terminal numbers on the counter are identical to those on the terminal socket.


Sockets (Unit: mm inch, Tolerance: $\pm 1 \pm .039$)

| Type | Appearance | Dimensions | Terminal wiring (Top view) | Mounting hole dimensions |
|---|---|---|---|--------------------------|
| LC4H (8-pin type) | <ul style="list-style-type: none"> • Rear terminal socket  <p>AT78041</p> |  |  | — |
| | <ul style="list-style-type: none"> • 8P cap  <p>AD8-RC</p> |  |  | — |
| LC4H LC4H-S LC4H-W (11-pin type) | <ul style="list-style-type: none"> • Rear terminal socket  <p>AT78051</p> |  |  | — |
| | <ul style="list-style-type: none"> • 11P cap  <p>AT8-DP11</p> |  |  | — |

Note: The terminal numbers on the counter are identical to those on the socket.

DIN SIZE COUNTERS COMMON OPTIONS

• Rubber gasket



ATC18002


Applicable for LC4H series

The rubber gasket is enclosed in the LC4H series.

• Mounting frame



AT8-DA4




Applicable for LC4H series

• Mounting rails (Applicable for DIN and IEC standards)




AT8-DLA1
Length: 1 m
aluminum



• Fastening plate




ATA4806



For holding DIN rails


• Protective cover for DIN 48 size

Hard type



AQM4801

Flexible type



AQM4803

• Panel cover (Black)

LC4H Panel cover (4 digits)



AEL58011

LC4H Panel cover (6 digits)




AEL58012

LC4H-S Panel cover (4 digits)




AEL58013

LC4H-S Panel cover (6 digits)



AEL58014

LC4H-W Panel cover (6 digits)



AEL68011

The black panel cover is also available so that you can change the appearance of the panel by changing the panel cover. The color of the standard panel cover is ash gray.